

TOP PANEL: Black chassis. 7 switched AUDIO UNITS AC outlets (with indicator light). 4 sequentially switched **POWER AMPLIFIERS** AC outlets: MAIN, 2, 3, and 4 (with individual indicator lights). 3 UNSWITCHED AC outlets. LED AC power indicator.



END PANEL: Power cord. Power **CONTROL**: INPUT.

The PC 2 has 14 AC outlets. Seven of the outlets are switched and can be controlled by any McIntosh Control Center or preamplifier. The seven switched accessory outlets turn on first. Approximately 1/2 second later, each of the four Power Amplifier outlets turn on in 1.2 second delayed sequence. This prevents a large instantaneous current inrush that could occur if four power amplifiers were turned on simultaneously. Three unswitched outlets remain on as long as the PC 2 main AC power cord is connected to a live AC wall outlet. Control is achieved by connecting the PC 2 AC control cable to the switched AC outlet on the accessory component, with the heavy PC 2 AC cable connected to a live AC wall outlet. Built-in McIntosh Surge Protectors and RFI filtering protect any equipment connected to the PC 2. LED power indicators are included for the switched outlets, the unswitched outlets and each of the four power amplifier outlets.

PC 2 - Sold from 1994 - 2000. S/N: GZ1001~GZ????

Size: 5-1/4"H, 11"W and 3-1/2"D. *Weight:* ? pounds. \$265.00

© 2007-2025 VintageMac – Larry Hodson