

FRONT PANEL: Chrome and black chassis. Terminal strips: input FROM POWER AMPLIFIERS:

LEFT, CENTER and RIGHT.

Output TO MAIN SPEAKERS: LEFT, CENTER and RIGHT.

✓





TOP PANEL: Connecting cord TO PREAMPLIFIER SPEAKER CONTROL RELAY RECEPTACLE.

BOTTOM PANEL: Power cord. 2 switched **AC** power **OUTLETS**.

SCR 1 - Sold from 1970 - 1971. S/N: ????~???? (??? UNITS)

Size: 6"H, 4"W and 2-1/2"D. **Weight:** ? lb. **\$49.50**