

# SCR 2

## SPEAKER CONTROL RELAY



**FRONT PANEL:** Chrome and black chassis. Terminal strips: Input FROM POWER AMPLIFIERS: LEFT, CENTER and RIGHT. ⚡ Output TO REMOTE SPEAKERS: LEFT, CENTER and RIGHT. ⚡ Output TO MAIN SPEAKERS: LEFT, CENTER and RIGHT.

**TOP PANEL:** Power cord. Connecting cord TO PREAMPLIFIER SPEAKER CONTROL RELAY RECEPTACLE.

**BOTTOM PANEL:** 2 switched AC power OUTLETS.

**SCR 2** - Sold from 1971 - 1992. S/N: BW1001~BW??? (??? UNITS)

**Size:** 6"H, 4"W and 2-1/2"D. **Weight:** ? lb. **\$200.00**